

# SECTION IX

## SUPPLEMENTAL DATA

INTRODUCTION . . . . . 9-2

REV A 9-23-82  
ISSUED 9-4-81

*Mooney* M20J

9-1 ■

SECTION IX  
SUPPLEMENTAL DATA

**INTRODUCTION**

FAA approved data pertaining to Limitations, Normal Procedures, Emergency Procedures, and effects on performance for certain optional equipment installed in the airplane are contained in this section. Commonly installed items of optional equipment whose function and operation do not require detailed instructions are described by Section VII.

MOONEY AIRCRAFT CORPORATION  
P. O. Box 72  
Kerrville, TX 78028

FAA APPROVED  
AIRPLANE FLIGHT MANUAL SUPPLEMENT  
FOR  
MOONEY MODELS M20C, M20J and M20K  
WITH  
KING KNS-80 RNAV SYSTEM

Model No. M20J

Reg. No. N1120W

Ser. No. 24-1316

This supplement must be attached to the applicable Airplane Flight Manual when the King KNS-80 RNAV System has been installed by Mooney Aircraft Corporation. The information contained herein supplements or supersedes the basic manual only in those areas listed herein. For limitations, procedures and performance information not contained in the supplement, consult the basic Airplane Flight Manual.

FAA APPROVED:

  
John P. Watson, Chief  
Engineering & Mfg. Branch  
FEDERAL AVIATION ADMINISTRATION  
Southwest Region, Fort Worth, TX

DATE: DEC 21 1978

Section I. - GENERAL.

The KNS-80 system contains one VOR/DME receiver combination when in the RNAV mode and has the capability for autopilot coupled operations. KNS-80 Area Navigation Computer includes a four waypoint memory for data storage and annunciation of conventional operating modes when selected. The system will retain its waypoint storage memory from its own battery power with the aircraft battery switch off.

1.1 HORIZONTAL SITUATION OR COURSE DEVIATION INDICATOR

1. COURSE SELECTOR Control - Used to set the magnetic course to the waypoint in either RNAV ENR or APR mode. Sets the magnetic course to the VOR ground station in VOR and VOR PAR mode.
2. VERTICAL DEVIATION BAR - Represents deviation from the selected magnetic course. Pointer moves left or right of the center line as airplane deviates from the selected magnetic course. Course width is 20 degrees in VOR mode, 10 nautical miles in RNAV ENR mode and 2-1/2 nautical miles in RNAV APR mode.
3. HORIZONTAL DEVIATION BAR\* - When the KNS 80 is tuned to an ILS frequency the horizontal deviation bar represents the deviation from the suggested glidepath. If the airplane is above the glidepath, the horizontal bar is displaced downward. If below the glidepath the horizontal bar is displaced upward.
4. TO/FROM POINTER - Indicates whether the selected magnetic course is TO or FROM the destination. The pointer reverses direction as the destination is passed.
5. WARNING FLAG - Shows if the Course Deviation data is unreliable. A black background appears if the Course Deviation data is reliable. If the data is not reliable, the TO/FROM flag disappears from view, and a red NAV flag appears.
6. LIGHTING - The CDI lighting is controlled by an instrument lighting rheostat which controls all instrument panel lighting.

\*Not applicable to systems without a glideslope.

Section II. - LIMITATIONS.

1. THE KNS 80 IN the RNAV MODE IS LIMITED TO VFR OPERATIONS ONLY UNLESS ACCURACY CERTIFIED PER AC 90-45A FOR IFR OPERATIONS. IFR APPROACHES MUST BE CONDUCTED IN ACCORDANCE WITH APPROVED INSTRUMENT APPROACH PROCEDURES. (PLACARD INSTALLED BELOW RIGHT END OF INSTRUMENT CLUSTER.)
2. IFR approaches must be conducted in accordance with FAA approved instrument approach procedures.
3. IFR Enroute use of the RNAV must be conducted in accordance with FAA approved RNAV routes or with a flight plan filed with and accepted by the applicable A.T.C. facility.
4. A/P coupled R/N approaches are prohibited. (Placard installed just above artificial horizon.)
5. VOR PAR mode prohibited during approach operation.
6. VOR/DME stations used for RNAV and VOR PAR operations must be collocated.

Section III. - EMERGENCY PROCEDURES.

NONE.

Section IV. - NORMAL PROCEDURES.

4.1 KNS 80 OPERATION

4.1.1 GENERAL

The KNS 80 can be operated in any of 3 basic modes: (a) VOR, (b) RNAV, or (c) ILS. To change from one mode to another, the appropriate pushbutton switch is pressed, except that the ILS mode is entered automatically whenever an ILS frequency is channeled in the USE waypoint. The display will annunciate the mode lighting a message above the pushbutton. In addition to the standard VOR and RNAV enroute (RNV ENR) modes, the KNS 80 has a constant course width or parallel VOR mode (VOR PAR) and an RNAV approach mode (RNV APR). To place the unit in either of these secondary modes the VOR pushbutton or the RNAV pushbutton, as the case may be, is pushed a second time. Repetitive pushing of the VOR button will cause the system to alternate between the VOR and VOR PAR modes, while repetitive pushing of the RNAV button causes the system to alternate between RNV ENR and RNV APR modes.

Section IV - Normal Procedures cont...

A description of the RNAV and VOR modes is as follows:

1. VOR

This is the conventional VOR/DME mode. The NM, KT- and MIN displays are DME outputs and the CDI is displaying conventional cross track deviation information (i.e.,  $\pm 10^\circ$  full scale).

2. VOR PAR

This is like the above mode except that the CDI is now displaying constant course width information with a full scale deflection of  $\pm 5\text{NM}$ . In this mode, a DME "unlock" will cause a CDI flag. Rechanneling the VOR with the HOLD button depressed will also cause a CDI flag. It is recommended that the VOR mode be used instead of VOR PAR for approaches since in this mode the course indication is more accurate at distances less than 28 nautical miles.

WARNING

VOR PAR information can be displayed during ILS or RNAV approaches but use is prohibited.

3. RNAV ENR

This RNAV mode has a CDI sensitivity of  $\pm 5\text{NM}$  full scale. The NM, KT and MIN displays as well as the CDI are now with respect to the waypoint as defined by the data stored in the USE waypoint location.

4. RNAV APR

This is like the above except that the CDI sensitivity is  $\pm 1.25\text{NM}$  full scale.

CAUTION

Autopilot approach steering is too sensitive for coupled approach operation and is prohibited.

All waypoint information, station frequency, waypoint distance, and waypoint radial is entered with the increment/decrement rotary switch on the right side of the panel and displayed in the right hand readout. The small knob affects the lower significant digits while the large knob changes the most significant digits. The tenth's position of waypoint radial and distance can be changed by pulling the small knob to the out position. The type of data

Section IV - Normal Procedures cont...

being displayed is indicated by the illuminated messages (FRQ, RAD, DST) located directly below the displayed data. Frequency, radial, or distance information for a waypoint can be displayed sequentially by pressing the "DATA" pushbutton. The increment/decrement switch changes only the information being displayed.

The KNS 80 can store frequency, radial, and distance information for up to 4 waypoints. The waypoint number of the data being displayed is located above the message DSP. The DSP waypoint number is changed by pressing DSP button. The number of the waypoint being used for navigation is indicated by the displayed waypoint, the DSP waypoint number blinks. Pressing the USE button causes the waypoint in use to match the displayed waypoint.

Normally, the DME is tuned to the station paired with the VOR frequency. The tuning of the DME may be frozen by depressing the HOLD button. Subsequent rechanneling of the NAV receiver will cause the HLD light to come on. The DME will "hold" the frequency it was tuned to at the time the button was depressed.

4.2 DETAILED FUNCTION DESCRIPTION

4.2.1 SYSTEM MODES

VOR, VOR PAR, RNV ENR and RNV APR are selected modes and have equal precedence. If an ILS frequency is placed in the active data, the system will automatically go to the ILS mode. When switched out of an ILS frequency the system will revert back to the mode in which it was at the time the ILS frequency was selected.

4.2.2 DISPLAYS

4.2.2.1 NM DISPLAY

1. VOR and VOR PAR Modes

Displays DME distance.  
0 to 99.9NM in 0.1NM steps, 100 to 200NM in 1NM steps.  
Displays dashes whenever DME goes into search.

2. RNV APR and RNV ENR Modes

Displays RNAV distance to waypoint.  
0 to 99.9NM in 0.1NM steps, 100 to 400NM in 1NM steps.  
Displays dashes if DME is in search, if VOR flags, or if the VOR is rechanneled with the HOLD button depressed.

Section IV - Normal Procedures cont...

4.2.2.2 KT DISPLAY

1. VOR and VOR PAR modes

Displays ground speed to the DME ground station.  
0 to 999 knots in 1 knot steps.  
Update rate is once per second.  
Displays dashes whenever DME goes into search.

2. RNV APR and RNV ENR Modes

Displays ground speed to the active waypoint.  
0 to 999 knots in 1 knot steps.  
Update rate is once per second.

Displays dashes whenever DME goes into search, if VOR flags or if the VOR is rechanneled with the HOLD button depressed.

4.2.2.3 MIN DISPLAY

1. VOR and VOR PAR Modes

Displays time to DME ground station.  
0 to 99 minutes in 1 minute steps.  
Displays dashes whenever DME goes into search or when calculated value exceeds 99 minutes.

2. RNV APR and RNV ENR Modes

Displays time to the active waypoint.  
0 to 99 minutes in 1 minute steps.  
Displays dashes if DME is in search, if VOR flags, if the VOR is rechanneled with the HOLD button depressed, or if calculated value exceeds 99 minutes.

4.2.2.4 FRQ. RAD. DST DISPLAY

1. FRQ Mode

Displays frequency from 108.00 to 117.95MHz.  
1MHz digit overflows into (or underflows from) 10MHz digit.  
Roll over from 117 to 108 or vice versa.  
Least significant digit displays only zero or five.

2. RAD Mode

Displays ground station radial on which the waypoint is located from 0.0 to 359.9 degrees.  
10 degree digit overflows into (or underflows from) 100 degree digit.

Section IV - Normal Procedures cont...

3. DST Mode

Displays the distance offset of the waypoint from the ground station over range of 0.0 to 199.9NM. 10NM digit overflows into (or underflows from) 100NM digit. The two most significant digits roll over from 190 to 0NM and vice versa.

4.2.2.5 USE DISPLAY

Displays waypoint number of data actually being used by system. In VOR MODES only the frequency has meaning. Range 1 to 4. When changed always takes on new value equal to DSP value.

4.2.2.6 DSP DISPLAY

Displays waypoint number of data being displayed. Range 1 to 4. When changed, increments by 1. Rolls over from 4 to 1 and blinks when not equal to USE value.

2.7 PAR, VOR, ENR, APR, RNV DISPLAYS

System status lights.

4.2.2.8 HLD DISPLAY

Indicates when the station to which the DME is actually tuned is different than the station to which the VOR is tuned.

4.2.2.9 DATA DISPLAY

Displays waypoint data. The messages FRQ, DST, and RAD tell what is being displayed at any one time.

4.2.2.10 ILS DISPLAY

Indicates that the frequency in use is an ILS frequency.

4.2.2.11 COURSE DEVIATION INDICATOR

1. VOR Mode

Full scale sensitivity equals  $\pm 10^\circ$ .

Section IV - Normal Procedures cont...

2. VOR PAR Mode

Full scale sensitivity equals +5NM.  
Flagged if VOR or DME data is Invalid.  
Flagged if the VOR is rechanneled with the DME HOLD button depressed.

3. RNV ENR Mode

Full scale sensitivity equals +5NM.  
Flagged if VOR or DME data is Invalid.  
Flagged if the VOR is rechanneled with the DME HOLD button depressed.

4. RNV APR Mode

Full scale sensitivity equals +1.25NM.  
Flagged if VOR or DME data is Invalid.  
Flagged if the VOR is rechanneled with the DME HOLD button depressed.

5. ILS Mode

Full scale sensitivity equals 3 to 6 degrees (depending upon ground facility).  
Flagged if localizer or glideslope data is invalid.

4.2.3 CONTROLS

4.2.3.1 VOR BUTTON

Momentary pushbutton.  
When pushed while system is in either RNV mode causes system to go to VOR mode. Otherwise the button causes system to toggle between VOR and VOR PAR modes.

4.2.3.2 RNAV BUTTON

Momentary pushbutton.  
When pushed while system is in either VOR mode causes system to go to RNV ENR mode. Otherwise the button causes system to toggle between RNV ENR and RNV APR modes.

4.2.3.3 HOLD BUTTON

Two position pushbutton.  
When in depressed position, inhibits DME from channeling to a new station when the VOR frequency is changed. Pushing the button again releases the button and channels the DME to the station paired with the VOR station.

Section IV - Normal Procedures cont...

4.2.3.4 USE BUTTON

Momentary pushbutton.  
Causes active waypoint to take on same value as displayed waypoint and data display to go to FRQ mode.

4.2.3.5 DSP BUTTON

Momentary pushbutton.  
Causes displayed waypoint to increment by 1 and data display to go to frequency mode.

4.2.3.6 DATA BUTTON

Momentary pushbutton.  
Causes waypoint data display to change from FRQ to RAD to DST and back to FRQ.

4.2.3.7 OFF/PULL ID CONTROL

1. Rotate counterclockwise to switch off power to the KNS 80.
2. Rotate clockwise to increase audio level.
3. Pull switch out to hear VOR Ident.

4.2.3.8 DATA INPUT CONTROL

Dual concentric knobs. Center knob has "in" and "out" positions.

1. Frequency Data

Outer knob varies 1MHz digit.  
A carryover occurs from the tens to hundreds place.  
Rollover occurs from 117 to 108.  
Center knob varies frequency in .05MHz steps regardless of whether the switch is in its in or out position.

2. Radial Data

Outer knob varies 10 degree digit.  
A carryover occurs from units to tens to hundreds position.  
A rollover to zero occurs at 360 degrees.  
Center knob "in" position varies 1 degree digit.  
Center knob "out" position varies 0.1NM digit.

3. Distance Data

Outer knob varies 10 NM digit.

Section IV - Normal Procedures cont...

3. Distance Data cont...

A carryover occurs from the tens to hundreds place.  
A rollover to zero occurs at 200NM.  
Center knob "in" position varies 1NM digit.  
Center knob "out" position varies 0.1NM digit.

4.2.3.9 COURSE SELECT KNOB

Located in CDI unit.  
Selects desired course through the VOR ground station  
or waypoint.

4.2.4 LIGHTING

Display lighting is automatically controlled by ambient  
light conditions. Button backlighting is controlled  
by an instrument lighting rheostat which controls all  
instrument panel lighting.

4.3 BATTERY REPLACEMENT

The waypoint memory is kept alive by two silver oxide  
watch cells located in the lower left hand corner of the  
front panel. Typical life of the cell is two years  
although high temperature and humidity conditions can  
shorten this period. If the battery should become weak,  
waypoint storage will be lost and the radio will "wake up"  
tuned to 100.00MHz in the VOR mode. The cells can be  
replaced by opening the battery pocket with a thin blade  
screwdriver. The holder was designed so that the cells can  
only be inserted with the correct polarity.

4.4 SYSTEM PERFORMANCE GROUND CHECK

The following test can be used to determine if the system  
is operating properly.

1. Tune the KNS 80 to a VORTAC (VOR/DME) within 25NM of  
the airplane.
2. Place the KNS 80 in VOR mode and rotate the OBS  
until the course deviation needle centers with the  
TO/FROM flag giving a "from" indication.
3. Place the KNS 80 in RNAV ENR mode.

The system is operating properly if the distance to  
station is within 1.0NM and the course deviation needle  
is within a dot of being centered.

MOONEY AIRCRAFT CORPORATION  
P.O. Box 72  
Kerrville, TX 78028

UNITED KINGDOM ADDENDUM  
TO  
FAA APPROVED  
AIRPLANE FLIGHT MANUAL SUPPLEMENT  
FOR  
MOONEY M20K S/N 25-0001 and UP  
MOONEY M20J S/N 24-0001 and UP  
WITH  
KING KFC 200 AUTOMATIC FLIGHT CONTROL SYSTEM  
WITH OR WITHOUT  
FLIGHT DIRECTOR

MODEL NO. M20J

REGISTRATION NO. N1170N

SERIAL NO. 24-1314

This United Kingdom Addendum must be used in conjunction with the F.A.A. Approved A.F.M. Supplement on King KFC 200 Automatic Flight Control System and the applicable Pilot's Operating Handbook when the KFC 200 Automatic Flight Control System is installed in accordance with drawing no. 830125. The information contained herein is in addition to the Basic A.F.M. Supplement.

For Limitations, Procedures and Performance information not contained in this addendum, consult the Basic Supplement and the Airplane Flight Manual.

UNITED KINGDOM ADDENDUM TO  
KFC 200 AUTOMATIC FLIGHT CONTROL SYSTEM (A.F.C.S.)

SECTION I.

General

This installation bulletin is FAA approved for incorporation in KFC 200 equipped airplanes. Incorporation of this installation bulletin will be required on all airplanes that have not been previously approved with a CWS Annunciator and are to be registered and approved in the United Kingdom. It is optional on all other KFC 200 installations.

FAA APPROVED Original signed by  
Ralph V. Cole  
Ralph V. Cole  
DER KC-249


SUBJECT: Addition of Control Wheel Steering (CWS) Annunciator Light

A control wheel steering (CWS) annunciator light will need to be incorporated on all KFC 200 equipped airplanes that are to be registered in the United Kingdom in the future. The addition of this annunciator light will require the installation of the following items:

<u>QUANTITY</u>	<u>DESCRIPTION</u>	<u>KING PART NUMBER</u>
1	Annunciator	037-0006-02
1	CWS Engaged Placard	057-2376-00
1	Diode	007-6022-00
1	Lamp 14V (for 14 VDC A/C)	037-0007-11
1	Lamp 28V (for 28 VDC A/C)	037-0007-02

These items should be ordered through King's Service Parts Department.

The Annunciator (KPN 037-0006-02) and the appropriate lamp should be installed in the pilot's instrument panel and located as close to the KA 285 annunciator panel as possible. The CWS ENGAGED placard (KPN 057-2376-00) should be installed adjacent to the annunciator. The annunciator should be wired in accordance with Figure 1 on the following page. The diode (007-6022-00) should be located as close to the KC 295 Flight Computer as possible. Install insulating tubing over the diode to avoid shorts to ground.



NOTE: 1. Eliminate this wire if airplane does not have a KA 141 AP Monitor.

FIGURE 1

Once this installation bulletin has been incorporated, the Airplane Flight Manual Supplement or Autopilot Flight Manual for airplanes that are to be registered in the United Kingdom shall be revised to include the following information. Revisions to these documents will not be necessary for other KFC 200 Installations.

SECTION II.

Limitations

Tabulate the following placard to those already listed:

CWS ENGAGED

Location: On pilot's instrument panel adjacent to CWS Engaged Light.

Minimum Height Limitations

The autopilot shall not be engaged or in use at heights less than 1,000 feet above the terrain,

except that:

When it is coupled to an ILS glide slope and the aircraft is in the approach configuration, it may remain engaged down to a height not less than 200 feet above the terrain.

SECTION III.

Emergency Procedures - No change.

SECTION IV.

Normal Procedures

1. Add the following sentence to the existing CWS switch function:

CWS .....  
..... It should be noted that all mode lights that were illuminated before the CWS switch was depressed, with the exception of GO AROUND, will remain illuminated while in the CWS mode.

2. Tabulate the following annunciator to those already listed:

CWS ENGAGED                      This warning light located on the upper portion of the pilot's instrument panel will illuminate when the CWS switch is held depressed.

3. Add the following test as part of the Preflight Check Procedure. (This test must be conducted with the AP engaged):

Depress the CWS switch and verify that the CWS ENGAGED Annunciator illuminates. While depressing the CWS switch, check for control column freedom to insure that the pitch and roll axis servo actuators have properly disengaged. Release the CWS switch and verify that the CWS ENGAGED Annunciator extinguishes. On releasing the switch also verify that pitch and roll axis servo actuators have properly re-engaged by applying force to the control column.

SECTION V.

Performance - No change.

C.A.A. APPROVED

  
A circular stamp with the text "AMERICAN AIRLINES" around the perimeter and "1981" at the bottom. The signature "James" is written across the stamp.

DATE: 26 OCT 1981